



Interrupts (I)


Lecturer: Sri Parameswaran
Notes by: Annie Guo





Lecture overview


- Introduction to Interrupts
 - Interrupt system specifications
 - Multiple sources of Interrupts
 - Interrupt priorities
- Interrupts in AVR
 - Interrupt Vector Table
 - Interrupt Service Routines
 - System Reset
 - Watchdog Reset



CPU Interacts with I/O


Two approaches:

- Polling
 - Software queries I/O devices.
 - No extra hardware needed.
 - Not efficient.
 - CPU may waste processor cycles to query a device even if it does not need any service.
- Interrupts
 - I/O devices generate signals to request services from CPU .
 - Need special hardware to implement interrupt services.
 - Efficient.
 - A signal is generated only if the I/O device needs services from CPU.




Interrupt Systems

- An interrupt system implements interrupt services
- It basically performs three tasks:
 - Recognize interrupt events
 - Respond to the interrupts
 - Resume normal programmed task




Recognize Interrupt Events

- Interrupt events
 - Associated with interrupt signals:
 - In different forms, including levels and edges.
 - Can be multiple and synchronous
 - Namely, there may be many sources to generate an interrupts; a number of interrupts can be generated at the same time.
- Approaches are required to:
 - Identify an interrupt event among multiple sources
 - Determine which interrupts to serve if there are multiple simultaneous interrupts




Respond to Interrupts

- Handling interrupt
 - Wait for the current instruction to finish.
 - Acknowledge the interrupting device.
 - Branch to the correct ***interrupt service routine*** (interrupt handler) to service interrupting device.



Resume Normal Task

- Return to the interrupted program at the point it was interrupted.




Interrupt Process Control


- Interrupts can be enabled or disabled
- Can be controlled in two ways:
 - Software control
 - Allow programmers to enable and disable selected/all interrupts.
 - Hardware control
 - Disable further interrupts while an interrupt is being serviced



Interrupt Recognition and Acknowledgement Hardware




Interrupt Recognition and Ack.




- An Interrupt Request (IRQ) may occur at any time.
 - It may have rising or falling edges or high or low levels.
 - Frequently it is an active-low signal
 - multiple devices are wire-ORed together.
 - Recall open-collector gates
- Signal Conditioning Circuit detects these different types of signals.
- Interrupt Request Flip-Flop (IRQ-FF) records the interrupt request until it is acknowledged.
 - When IRQ-FF is set, it generates a pending interrupt signal that goes towards the Sequence Controller.
 - IRQ-FF is reset when CPU acknowledges the interrupt with INTA signal.

Interrupt Recognition and Ack. (cont.)




- Interrupts can be enabled and disabled by software instructions, which is supported by the hardware Interrupt Enable Flip-Flop (INTE-FF).
- When the INTE-FF is set, all interrupts are enabled and the pending interrupt is allowed through the AND gate to the sequence controller.
- The INTE-FF is reset in the following cases.
 - CPU acknowledges the interrupt.
 - CPU is reset.
 - Disable interrupt instruction is executed.

Interrupt Recognition and Ack. (cont.)




- An interrupt acknowledge signal is generated by the CPU when the current instruction has finished execution and CPU has detected the IRQ.
 - This resets the IRQ-FF and INTE-FF and signals the interrupting device that CPU is ready to execute the interrupting device routine.
- At the end of the interrupt service routine, CPU executes a return-from-interrupt instruction.
 - Part of this instruction's job is to set the INTE-FF to re-enable interrupts.
- Nested interrupts can happen If the INTE-FF is set during an interrupt service routine
 - An interrupt can therefore interrupt interrupting interrupts.

Multiple Sources of Interrupts





- To handle multiple sources of interrupts, the interrupt system must
 - Identify which device has generated the IRQ.
 - Using polling approach
 - Using vectoring approach
 - Resolve simultaneous interrupt requests
 - using prioritization schemes.





Polled Interrupts


- Software, instead of hardware, is responsible for finding the interrupting source.
 - The device must have logic to generate the IRQ signal and to set an “I did it” bit in a status register that is read by CPU.
 - The bit is reset after the register has been read.

Polled Interrupts Execution Flow



Polled Interrupt Logic








Vectored Interrupts

- CPU's response to IRQ is to assert INTA.
- The interrupting device uses INTA to place information that identifies itself, called the vector, onto the data bus for CPU to read.
- CPU uses the vector to execute the interrupt service routine.

Vectored Interrupting Device Hardware









Multiple Interrupt Masking

- CPU has multiple IRQ input pins.
- Masking enables some interrupts and disables other interrupts
- CPU designers reserve specific memory locations for a vector associated with each IRQ line.
- Individual disable/enable bit is assigned to each interrupting source.


Multiple Interrupt Masking Circuit






Interrupt Priorities



- When multiple interrupts occur at the same time, which one will be serviced first?
- Two resolution approaches:
 - Software resolution
 - Polling software determines which interrupting source is serviced first.
 - Hardware resolution
 - Daisy chain.
 - Others




Software Resolution




Daisy Chain Priority Resolution



Daisy Chain Priority Resolution (cont.)




- CPU asserts INTA that is passed down the chain from device to device. The higher-priority device is closer to CPU.
- When the INTA reaches a device that generated the IRQ, that device puts its vector on the data bus and does not pass along the INTA. So lower-priority devices do NOT receive the INTA.




Other Priority Resolutions

- Separate IRQ Lines.
 - Each IRQ line is assigned a fixed priority. For example, IRQ0 has higher priority than IRQ1 and IRQ1 has higher priority than IRQ2 and so on.
- Hierarchical Prioritization.
 - Higher priority interrupts are allowed while lower ones are masked.
- Nonmaskable Interrupts.
 - Cannot be disabled.
 - Used for important events such as power failure.

Transferring Control to Interrupt Service Routine




- Hardware needs to save the return address.
 - Most processors save the return address on the stack.
- Hardware may also save some registers such as program status register.
 - AVR does not save any registers. It is the programmers' responsibility to save the program status register and conflict registers.
- The delay from the time the IRQ is generated by the interrupting device to the time the Interrupt Service Routine (ISR) starts to execute is called *interrupt latency*.




Interrupt Service Routine

- A sequence of code to be executed when the corresponding interrupt is responded by CPU.
- Interrupt service routine is a special subroutine, therefore can be constructed with three parts:
 - Prologue:
 - Code for saving conflict registers on the stack.
 - Body:
 - Code for doing the required task.
 - Epilogue:
 - Code for restoring all saved registers from the stack.
 - The last instruction is the return-from-interrupt instruction.




Software Interrupt

- Software interrupt is the interrupt generated by software without a hardware-generated-IRQ.
- Software interrupt is typically used to implement system calls in OS.
- Some processors have a special machine instruction to generate software interrupt.
 - SWI in ARM.
- AVR does NOT provide a software interrupt instruction.
 - Programmers can use External Interrupts to implement software interrupts.




Exceptions

- Abnormalities that occur during the normal operation of the processor.
 - Examples are internal bus error, memory access error and attempts to execute illegal instructions.
- Some processors handle exceptions in the same way as interrupts.
 - AVR does not handle exceptions.




Reset


- Reset is a type of interrupt present in most processors (including AVR).
- Non-maskable.
- It does not do other interrupt processes, such as saving context registers. It initializes the system to some initial state.



Non-Nested Interrupts


- Interrupt service routines cannot be interrupted by another interrupt.






Nested Interrupts

- Interrupt service routines can be interrupted by another interrupt.






AVR Interrupts


- Basically can be divided into internal and external interrupts
- Each has a dedicated interrupt vector
- Hardware is used to recognize interrupts
- To enable an interrupt, two control bits must be set
 - the Global Interrupt Enable bit (I bit) in the Status Register
 - Using `sei`
 - the enable bit for that interrupt
- To disable all maskable interrupts, reset the I bit in SREG
 - Using `cli` instruction
- Priority of interrupts is used to handle multiple simultaneous interrupts

Set Global Interrupt Flag



- Syntax: *sei*
- Operands: none
- Operation: $I \leftarrow 1$.
 - Sets the global interrupt flag (I) in SREG. The instruction following SEI will be executed before any pending interrupts.
- Words: 1
- Cycles: 1
- Example:


```
sei    ; set global interrupt enable
sleep ; enter sleep state, waiting for an interrupt
```



Clear Global Interrupt Flag


- Syntax: *cli*
- Operands: none
- Operation: $I \leftarrow 0$
 - Clears the Global interrupt flag in SREG. Interrupts will be immediately disabled.
- Words: 1
- Cycles: 1
- Example:

```
in r18, SREG          ; store SREG value
cli                   ; disable interrupts
; do something very important here
out SREG, r18         ; restore SREG value
```



Interrupt Response Time

- The interrupt execution response for all the enabled AVR interrupts is basically five clock cycles minimum.
 - For saving the Program Counter (2 clock cycles)
 - For jumping to the interrupt routine (3 clock cycles)



Interrupt Vectors


- Each interrupt has a 4-byte (2-word) interrupt vector, containing an instruction to be executed after MCU has accepted the interrupt.
- The lowest addresses in the program memory space are by default defined as the section for Interrupt Vectors.
- The priority of an interrupt is based on the position of its vector in the program memory
 - The lower the address the higher is the priority level.
- RESET has the highest priority

Interrupt Vectors in Mega2560




Vector No.	Program Address ⁽²⁾	Source	Interrupt Definition
1	\$0000 ⁽¹⁾	RESET	External Pin, Power-on Reset, Brown-out Reset, Watchdog Reset, and JTAG AVR Reset
2	\$0002	INT0	External Interrupt Request 0
3	\$0004	INT1	External Interrupt Request 1
4	\$0006	INT2	External Interrupt Request 2
5	\$0008	INT3	External Interrupt Request 3
6	\$000A	INT4	External Interrupt Request 4
7	\$000C	INT5	External Interrupt Request 5
8	\$000E	INT6	External Interrupt Request 6
9	\$0010	INT7	External Interrupt Request 7
10	\$0012	PCINT0	Pin Change Interrupt Request 0
11	\$0014	PCINT1	Pin Change Interrupt Request 1
12	\$0016 ⁽³⁾	PCINT2	Pin Change Interrupt Request 2

Interrupt Vectors in Mega2560 (cont.)




13	\$0018	WDT	Watchdog Time-out Interrupt
14	\$001A	TIMER2 COMPA	Timer/Counter2 Compare Match A
15	\$001C	TIMER2 COMPB	Timer/Counter2 Compare Match B
16	\$001E	TIMER2 OVF	Timer/Counter2 Overflow
17	\$0020	TIMER1 CAPT	Timer/Counter1 Capture Event
18	\$0022	TIMER1 COMPA	Timer/Counter1 Compare Match A
19	\$0024	TIMER1 COMPB	Timer/Counter1 Compare Match B
20	\$0026	TIMER1 COMPC	Timer/Counter1 Compare Match C
21	\$0028	TIMER1 OVF	Timer/Counter1 Overflow
22	\$002A	TIMER0 COMPA	Timer/Counter0 Compare Match A
23	\$002C	TIMER0 COMPB	Timer/Counter0 Compare match B
24	\$002E	TIMER0 OVF	Timer/Counter0 Overflow
25	\$0030	SPI, STC	SPI Serial Transfer Complete
26	\$0032	USART0 RX	USART0 Rx Complete
27	\$0034	USART0 UDRE	USART0 Data Register Empty
28	\$0036	USART0 TX	USART0 Tx Complete
29	\$0038	ANALOG COMP	Analog Comparator

Interrupt Vectors in Mega2560 (cont.)




30	\$003A	ADC	ADC Conversion Complete
31	\$003C	EE READY	EEPROM Ready
32	\$003E	TIMER3 CAPT	Timer/Counter3 Capture Event
33	\$0040	TIMER3 COMPA	Timer/Counter3 Compare Match A
34	\$0042	TIMER3 COMPB	Timer/Counter3 Compare Match B
35	\$0044	TIMER3 COMPC	Timer/Counter3 Compare Match C
36	\$0046	TIMER3 OVF	Timer/Counter3 Overflow
37	\$0048	USART1 RX	USART1 Rx Complete
38	\$004A	USART1 UDRE	USART1 Data Register Empty
39	\$004C	USART1 TX	USART1 Tx Complete
40	\$004E	TWI	2-wire Serial Interface
41	\$0050	SPM READY	Store Program Memory Ready

Interrupt Vectors in Mega2560 (cont.)




41	\$0050	SPM READY	Store Program Memory Ready
42	\$0052 ⁽³⁾	TIMER4 CAPT	Timer/Counter4 Capture Event
43	\$0054	TIMER4 COMPA	Timer/Counter4 Compare Match A
44	\$0056	TIMER4 COMPB	Timer/Counter4 Compare Match B
45	\$0058	TIMER4 COMPC	Timer/Counter4 Compare Match C
46	\$005A	TIMER4 OVF	Timer/Counter4 Overflow
47	\$005C ⁽³⁾	TIMER5 CAPT	Timer/Counter5 Capture Event
48	\$005E	TIMER5 COMPA	Timer/Counter5 Compare Match A
49	\$0060	TIMER5 COMPB	Timer/Counter5 Compare Match B
50	\$0062	TIMER5 COMPC	Timer/Counter5 Compare Match C
51	\$0064	TIMER5 OVF	Timer/Counter5 Overflow
52	\$0066 ⁽³⁾	USART2 RX	USART2 Rx Complete
53	\$0068 ⁽³⁾	USART2 UDRE	USART2 Data Register Empty
54	\$006A ⁽³⁾	USART2 TX	USART2 Tx Complete
55	\$006C ⁽³⁾	USART3 RX	USART3 Rx Complete
56	\$006E ⁽³⁾	USART3 UDRE	USART3 Data Register Empty
57	\$0070 ⁽³⁾	USART3 TX	USART3 Tx Complete



Interrupt Process


- When an interrupt occurs, the Global Interrupt Enable I-bit is cleared and all interrupts are disabled.
- The interrupt routine can set the I-bit to allow nested interrupts
- The I-bit is automatically set when a Return from Interrupt instruction – RETI – is executed.
- When the AVR exits from an interrupt, it will always return to the main program and execute one more instruction before any pending interrupt is served.
 - Reset interrupt is an exception

Initialization of Interrupt Vector Table in Mega2560



- Typically an interrupt vector contains a branch instruction (JMP or RJMP) that branches to the first instruction of the interrupt service routine.
- Or simply RETI (return-from-interrupt) if you don't handle this interrupt.

Example of IVT Initialization in Mega2560



```
.include "m2560def.inc"


.cseg

.org 0x0000      ; Reset vector is at address 0x0000
rjmp RESET      ; Jump to the start of Reset interrupt service routine
                ; Relative jump is used assuming RESET is not far

.org INT0addr    ; Addresses of vectors are defined in m2560def.inc
jmp IRQ0         ; Long jump is used assuming IRQ0 is very far away


.org INT1addr

reti            ; Return to the break point without handling the interrupt
...
RESET:          ; The interrupt service routine for RESET starts here.
...
IRQ0:           ; The interrupt service routine for IRQ0 starts here.
```



RESET in Mega2560



- The ATmega2560 has five sources of reset:
 - Power-on Reset.
 - The MCU is reset when the supply voltage is below the Power-on Reset threshold (VPOT).
 - External Reset.
 - The MCU is reset when a low level is present on the RESET pin for longer than the minimum pulse length.
 - Watchdog Reset.
 - The MCU is reset when the Watchdog Timer period expires and the Watchdog is enabled.





RESET in Mega2560 (Cont.)

- Brown-out Reset.
 - The MCU is reset when the supply voltage VCC is below the Brown-out Reset threshold (VBOT) and the Brown-out Detector is enabled.
- JTAG AVR Reset.
 - The MCU is reset as long as there is a logic one in the Reset Register, one of the scan chains of the JTAG system.
- For each reset, there is a flag (bit) in MCU Control and State Register MCUCSR.
 - These bits are used to determine the source of the RESET interrupt.


RESET Logic in Mega2560



Atmega2560 Pin Configuration




Source: Atmega2560 Data Sheet



Watchdog Timer



- A peripheral I/O device on the microcontroller.
- It is really a counter that is clocked from a separate On-chip Oscillator (122 kHz at $V_{cc}=5V$)
- It can be controlled to produce different time intervals
 - 8 different periods determined by WDP2, WDP1 and WDP0 bits in WDTCSR.
- Can be enabled or disabled by properly updating WDCE bit and WDE bit in Watchdog Timer Control Register WDTCSR.



Watchdog Timer (cont.)


- Often used to detect software crash.
 - If enabled, it generates a Watchdog Reset interrupt when its period expires.
 - When its period expires, Watchdog Reset Flag WDRF in MCU Control Register MCUCSR is set.
 - This flag is used to determine if the watchdog timer has generated a RESET interrupt.
 - Program needs to reset it before its period expires by executing instruction *WDR*.

Watchdog Timer Diagram



Source: Atmega2560 Data Sheet


Watchdog Timer Control Register



- WDTCSR is used to control the scale of the watchdog timer. It is an MM I/O register in AVR


Bit	7	6	5	4	3	2	1	0	
(0x60)	WDIF	WDIE	WDP3	WDCE	WDE	WDP2	WDP1	WDP0	WDTCSR
Read/Write	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	
Initial Value	0	0	0	0	X	0	0	0	

Source: Atmega2560 Data Sheet



WDTCSR Bit Definition


- Bit 7 – WDIF - Watchdog interrupt flag
- Bit 6 – WDIE - Watchdog interrupt enable
- Bit 4
 - WDCE - Watchdog change enable
 - Should be set before any changes to be made
- Bit 3
 - WDE - Watchdog enable
 - Set to enable watchdog; clear to disable the watchdog
- Bits 5,2-0
 - Prescaler
 - Named WDP3, WDP2, WDP1, WPD0
 - Determine the watchdog time reset intervals



Watchdog Timer Prescale

WDP3	WDP2	WDP1	WDP0	Number of WDT Oscillator Cycles	Typical Time-out at $V_{CC} = 5.0V$
0	0	0	0	2K (2048) cycles	16ms
0	0	0	1	4K (4096) cycles	32ms
0	0	1	0	8K (8192) cycles	64ms
0	0	1	1	16K (16384) cycles	0.125s
0	1	0	0	32K (32768) cycles	0.25s
0	1	0	1	64K (65536) cycles	0.5s
0	1	1	0	128K (131072) cycles	1.0s
0	1	1	1	256K (262144) cycles	2.0s
1	0	0	0	512K (524288) cycles	4.0s
1	0	0	1	1024K (1048576) cycles	8.0s

Source: Atmega64 Data Sheet




Examples

- Enable watchdog

```
; Write logical one to WDE
```

```
ldi r16, (1<<WDE)
```

```
sts WDTCR, r16
```

Examples


- Disable watchdog
 - Refer to the data sheet

```
; Write logical one to WDCE and WDE
```

```
ldi r16, (1<<WDCE)|(1<<WDE)  
sts WDTCR, r16
```

```
; Turn off WDT
```

```
ldi r16, (0<<WDE)  
sts WDTCR, r16
```



Examples

- Select a prescale
 - Refer to the data sheet

```
; Write logical one to WDCE and WDE
```


```
ldi r16, (1<<WDCE)|(1<<WDE)
```

```
sts WDTCR, r16
```

```
; set time-out as 1 second
```


```
ldi r16, (1<<WDP2)|(1<<WDP1)
```

```
sts WDTCR, r16
```



Watchdog Reset

- Syntax: *wdr*
- Operands: none
- Operation: reset the watchdog timer.
- Words: 1
- Cycles: 1



Example

- The program in the next slide is not robust. May lead to a crash. Why? How to detect the crash?



; The program returns the length of a string.

```
.include "m2560def.inc"
.def i=r15           ; store the string length when execution finishes.
.def c=r16           ; store s[i], a string character


.cseg

main:
    ldi ZL, low(s<<1)
    ldi ZH, high(s<<1)
    clr i
    lpm c, z+

loop:
    cpi c, 0
    breq endloop
    inc i
    lpm c, Z+
    rjmp loop


endloop:...

s: .db "hello, world"
```




Reading Material

- Chapter 8: Interrupts and Real-Time Events. Microcontrollers and Microcomputers by Fredrick M. Cady.
- Mega2560 Data Sheet.
 - System Control and Reset.
 - Watchdog Timer.
 - Interrupts.



Homework

1. Refer to the AVR Instruction Set manual, study the following instructions:
 - Bit operations
 - `sei, cli`
 - `sbi, cbi`
 - MCU control instructions
 - `wdr`



Homework

1. What is the function of the following code?


```
; Write logical one to WDCE and WDE
    ldi r16, (1<<WDCE)|(1<<WDE)
    sts WDTCSR, r16

; set time-out as 2.1 second
    ldi r16, (1<<WDP2)|(1<<WDP1)|(1<<WDP0)
    sts WDTCSR, r16

; enable watchdog
    ldi r16, (1<<WDE)
    sts WDTCSR, r16


loop: oneSecondDelay    ; macro for one second delay
    wdr
    rjmp loop
```


Homework



2. How an I/O device signals the microprocessor that it needs service?

Homework



3. Why do you need software to disable interrupts (except for the non-maskable interrupts)?