


DESN2000 (Computer Engineering) 2026 T2

ARM Assembly

Hasindu Gamaarachchi




ARM Assembly

- This is a crash course, well a “crash lecture”!
- Assumes prior learning of an assembly language
 - MIPS in COMP1521
- ARM is a Reduced Instruction Set Computer (RISC) architecture
 - Conceptually a lot of similarities to MIPS
 - And yeh, there are some differences


Learning Resources

The upcoming slides are adapted from “Embedded Systems with ARM Cortex-M Microcontrollers in Assembly Language and C (Fourth Edition)” – Yifeng Zhu

- ARM Instruction set architecture - chapter 3
- For an in-depth understanding of ARM assembly programming – chapters 4-8
- Mixing C and assembly – chapter 10



ARM Processor Register Bank



- Each register is 32 bits
- R0-R12: General purpose registers
- R13: Stack pointer (SP)
- R14: Link Register (LR)
- R15: Program Counter (PC)

ARM Instruction Examples

ADD r0, r2, r3 // r0 = r2 + r3

mnemonic destination operand 1st source operand 2nd source operand comment

The diagram shows the instruction 'ADD r0, r2, r3 // r0 = r2 + r3'. Red horizontal lines underline each token: 'ADD', 'r0,', 'r2,', 'r3', and '// r0 = r2 + r3'. Red arrows point from labels below to these underlined tokens: 'mnemonic' points to 'ADD', 'destination operand' points to 'r0,', '1st source operand' points to 'r2,', '2nd source operand' points to 'r3', and 'comment' points to '// r0 = r2 + r3'.

ARM Instruction Examples

ADD r1, r2, r3 // r1 = r2 + r3

ADD r1, r2, #4 // r1 = r2 + 4

MOV r0, r1 // r0 = r1

MOV r1, #5 // r1 = 5

ARM Assembly Instructions

- Arithmetic and logic
 - Add, Subtract, Multiply, Divide, Shift, Rotate
- Data movement
 - Load, Store, Move
- Compare and branch
 - Compare, If-then, branch,
- Miscellaneous
 - Breakpoints, wait for events, no operation

Arithmetic Instructions: Examples

- **ADD** `r0, r1, r2` // `r0 = r1 + r2`
- **ADC** `r0, r1, r2` // Add with carry, `r0 = r1 + r2 + carry`
- **SUB** `r0, r1, r2` // `r0 = r1 - r2`
- **SBC** `r0, r1, r2` // Subtract with borrow, `r0 = r1 - r2 - (1 - carry)`
- **MUL** `r0, r1, r2` // `r0 = r1 * r2`, product limited to 32 bits

Logic Instructions: Examples

- **AND** `r0, r1, r2` // Bitwise AND, `r0 = r1 AND r2`
- **ORR** `r0, r1, r2` // Bitwise OR, `r0 = r1 OR r2`
- **EOR** `r0, r1, r2` // Bitwise Exclusive OR, `r0 = r1 EOR r2`
- **ORN** `r0, r1, r2` // Bitwise OR NOT, `r0 = r1 ORN r2`

- **BIC** `r0, r1, r2` // Bit clear, `r0 = r1 & ~r2`

- **LSL** `r0, r1, r2` // Logical shift left, `r0 = r1 << r2`
- **LSR** `r0, r1, r2` // Logical shift right, `r0 = r1 >> r2`
- **ROR** `r0, r1, r2` // Rotate right, `r0 = r1 rotate by r2 bits`

Data Movement Instructions: Examples

- **MOV** r1, r0 // r1 = r0
- **MOV** r1, #16 // r1 = 16
- **LDR** r1, =10000 // r1 = 10000

// assume r0 has the memory address

- **LDR** r1, [r0] // r1 = Memory.word[r0]
- **LDR** r1, [r0,#8] // r1 = Memory.word[r0+8]

; assume r0 has the memory address

- **STR** r1, [r0] // Memory.word[r0] = r1
- **STR** r1, [r0,#8] // Memory.word[r0+8] = r1

Compare and branch Instructions: Examples

```
C Program
if (a == 1)
    b = 3;
else
    b = 4;
```

If-then-else

```
        // r1 = a, r2 = b
        CMP r1, #1    // compare a and 1
        BNE else      // go to else if a ≠ 1
then:    MOV r2, #3    // b = 3
        B   endif     // go to endif
else:    MOV r2, #4    // b = 4
endif:
```

Compare and branch Instructions: Examples


C Program

```
int i;  
int sum = 0;  
for(i = 0; i < 10; i++){  
    sum += i;  
}
```

For Loop

```
MOV r0, #0    // i  
MOV r1, #0    // sum  
  
loop:  CMP r0, #10        // compare i and 10  
        BGE stop          // end loop if i>=10  
        ADD r1, r1, r0     // sum += i  
        ADD r0, r0, #1     // i++  
        B loop             // loop  
  
stop:
```

Compare and branch Instructions: Examples




Miscellaneous Instructions: Examples

- **NOP** // No Operation

Function Calls – Calling Standard

- What is it?
 - Contract between a caller and callee
 - Why need it?
 - Allows functions to be separately written, compiled, and assembled but work together
 - Allows C program call an assembly function, or vice versa
 - Involves:
 - Argument passing
 - Return values
 - Backing up registers
- Calling standard is also known by terms like calling convention

Passing Arguments and Returning Value



Passing Arguments and Returning Value

```
int32_t sum(int32_t a, int32_t b, int32_t c, int32_t d);
```

```
s = sum(1, 2, 3, 4);
```

Caller

```
MOV r0, #1 // a
MOV r1, #2 // b
MOV r2, #3 // c
MOV r3, #4 // d
BL    sum
```

Callee

```
sum:
    ADD r0, r0, r1 // a + b
    ADD r0, r0, r2 // add c
    ADD r0, r0, r3 // add d
    BX  LR
```

Preserving registers

Caller Saved Registers	R0
	R1
	R2
	R3
Callee Saved Registers	R4
	R5
	R6
	R7
	R8
	R9
	R10
	R11
	R12
	R13 (SP)
	R14 (LR)
	R15 (PC)

- Callee can freely modify R0, R1, R2, and R3
- If caller expects their values are retained, caller should push them onto the stack before calling the callee
- Caller expects these values are retained .
- If Callee modifies them, callee must restore their values upon leaving the function.

Preserving registers

Caller Program	Subroutine/Callee
<pre>MOV r4, #100 ... BL foo ... ADD r4, r4, #1 // r4 = 101, not 11</pre>	<pre>foo: PUSH {r4} // preserve r4 ... MOV r4, #10 // foo changes r4 ... POP {r4} // Recover r4 BX LR</pre>

Caller expects callee does not modify r4!

Callee should preserve r4!

Mixing C and Assembly

- Inline assembly

```
// ...  
// C code  
__asm__(  
    "MOV r0, #0x048000000 \n"  
    "LDR r1, [r0, #0x14] \n"  
    "BIC r1, r1, #1<<5 \n"  
    "STR r1, [r0, #0x14] \n"  
);  
//...  
// C code
```

Mixing C and Assembly

- Calling as assembly function from C

C Program (main.c)	Assembly Program (strlen.s)
<pre>char str[25] = "Hello!"; int strlen(char* s); int main(void){ int i; i = strlen(str); while(1); }</pre>	<pre>.global strlen strlen: PUSH {r4} // preserve r4 MOV r4, #0 // initialize length loop: LDRB r1, [r0, r4] // r0 = string address CBZ r1, exit // branch if zero ADD r4, r4, #1 // length++ B loop // do it again exit: MOV r0, r4 // place result in r0 POP {r4} // return BX LR</pre>

Arithmetic and Logic Instructions

- **Shift** : **LSL** (logic shift left), **LSR** (logic shift right), **ASR** (arithmetic shift right), **ROR** (rotate right), **RRX** (rotate right with extend)
- **Logic**: **AND** (bitwise and), **ORR** (bitwise or), **EOR** (bitwise exclusive or), **ORN** (bitwise or not), **MVN** (move not)
- **Bit set/clear**: **BFC** (bit field clear), **BFI** (bit field insert), **BIC** (bit clear), **CLZ** (count leading zeroes)
- **Bit/byte reordering**: **RBIT** (reverse bit order in a word), **REV** (reverse byte order in a word), **REV16** (reverse byte order in each half-word independently), **REVSH** (reverse byte order in each half-word independently)
- **Addition**: **ADD**, **ADC** (add with carry)
- **Subtraction**: **SUB**, **RSB** (reverse subtract), **SBC** (subtract with carry)
- **Multiplication**: **MUL** (multiply), **MLA** (multiply-accumulate), **MLS** (multiply-subtract), **SMULL** (signed long multiply-accumulate), **SMLAL** (signed long multiply-accumulate), **UMULL** (unsigned long multiply-subtract), **UMLAL** (unsigned long multiply-subtract)
- **Division**: **SDIV** (signed), **UDIV** (unsigned)
- **Saturation**: **SSAT** (signed), **USAT** (unsigned)
- **Sign extension**: **SXTB** (signed), **SXTH**, **UXTB**, **UXTH**
- **Bit field extract**: **SBFX** (signed), **UBFX** (unsigned)

Load/Store a Byte, Halfword, Word

LDRxxx R0, [R1]

// Load data from memory into a 32-bit register

LDR	Load Word	uint32_t/int32_t	unsigned or signed int
LDRB	Load B yte	uint8_t	unsigned char
LDRH	Load H alfword	uint16_t	unsigned short int
LDRSB	Load S igned B yte	int8_t	signed char
LDRSH	Load S igned H alfword	int16_t	signed short int

STRxxx R0, [R1]

// Store data extracted from a 32-bit register into memory

STR	Store Word	uint32_t/int32_t	unsigned or signed int
STRB	Store Lower B yte	uint8_t/int8_t	unsigned or signed char
STRH	Store Lower H alfword	uint16_t/int16_t	unsigned or signed short

Pre-index and Post-index

Index Format	Example	Equivalent
Pre-index	LDR r1, [r0, #4]	$r1 \leftarrow \text{memory}[r0 + 4]$, r0 is unchanged
Pre-index with update	LDR r1, [r0, #4]!	$r1 \leftarrow \text{memory}[r0 + 4]$ $r0 \leftarrow r0 + 4$
Post-index	LDR r1, [r0], #4	$r1 \leftarrow \text{memory}[r0]$ $r0 \leftarrow r0 + 4$


Offset range is -255 to +255

Unconditional Branch Instructions

Instruction	Operands	Brief description
B	label	Branch
BL	label	Branch with Link
BX	Rm	Branch indirect

- ***B label***
 - perform a branch to label.
- ***BL label***
 - copy the address of the next instruction into r14 (lr, the link register), and
 - perform a branch to label.
- ***BX Rm***
 - branch to the address held in Rm

Condition Flags



- **Negative** bit
 - $N = 1$ if most significant bit of result is 1
- **Zero** bit
 - $Z = 1$ if all bits of the result are 0
- **Carry** bit
 - For unsigned addition, $C = 1$ if carry takes place
 - For unsigned subtraction, $C = 0$ (carry = not borrow) if borrow takes place
 - For shift/rotation, $C =$ last bit shifted out
- **oVerflow** bit
 - $V = 1$ if adding 2 same-signed numbers produces a result with the opposite sign
 - Positive + Positive = Negative, or
 - Negative + negative = Positive
 - Non-arithmetic operations does not touch V bit, such as MOV, AND, LSL, MUL

Branch Instructions

	Instruction	Description	Flags tested
Conditional Branch	BEQ label	Branch if E qual	Z = 1
	BNE label	Branch if N ot E qual	Z = 0
	BCS/BHS label	Branch if unsigned H igher or S ame	C = 1
	BCC/BLO label	Branch if unsigned L ower	C = 0
	BMI label	Branch if M inus (Negative)	N = 1
	BPL label	Branch if P lus (Positive or Zero)	N = 0
	BVS label	Branch if o V erflow S et	V = 1
	BVC label	Branch if o V erflow C lear	V = 0
	BHI label	Branch if unsigned H igher	C = 1 & Z = 0
	BLS label	Branch if unsigned L ower or S ame	C = 0 or Z = 1
	BGE label	Branch if signed G reater or E qual	N = V
	BLT label	Branch if signed L ess T han	N != V
	BGT label	Branch if signed G reater T han	Z = 0 & N = V
	BLE label	Branch if signed L ess than or E qual	Z = 1 or N = !V

ARM Procedure Call Standard

Register	Usage	Subroutine Preserved	Notes
r0	Argument 1 and return value	No	If return has 64 bits, then r0:r1 hold it. If argument 1 has 64 bits, r0:r1 hold it.
r1	Argument 2	No	
r2	Argument 3	No	If the return has 128 bits, r0-r3 hold it.
r3	Argument 4	No	If more than 4 arguments, use the stack
r4	General-purpose V1	Yes	Variable register 1 holds a local variable.
r5	General-purpose V2	Yes	Variable register 2 holds a local variable.
r6	General-purpose V3	Yes	Variable register 3 holds a local variable.
r7	General-purpose V4	Yes	Variable register 4 holds a local variable.
r8	General-purpose V5	YES	Variable register 5 holds a local variable.
r9	Platform specific/V6	Yes/No	Usage is platform-dependent. Can be Variable register 6
r10	General-purpose V7	Yes	Variable register 7 holds a local variable.
r11	General-purpose V8	Yes	Variable register 8 holds a local variable.
r12 (IP)	Intra-procedure-call register	No	It holds intermediate values between a procedure and the sub-procedure it calls.
r13 (SP)	Stack pointer	Yes	SP has to be the same after a subroutine has completed.
r14 (LR)	Link register	No	LR does not have to contain the same value after a subroutine has completed.
r15 (PC)	Program counter	N/A	Do not directly change PC

ARM Cortex Instruction Set

- [https://web.eece.maine.edu/~zhu/book/Appendix B Cortex M3 M4 Instructions.pdf](https://web.eece.maine.edu/~zhu/book/Appendix%20B%20Cortex%20M3%20M4%20Instructions.pdf)

ARM Immediate Values

- Following posts would be helpful those who want to know how and what immediate values are supported in ARM instructions
 - [https://xlogicx.net/ARM 12-bit Immediates are Too High Level.html](https://xlogicx.net/ARM%2012-bit%20Immediates%20are%20Too%20High%20Level.html)
 - [https://minhhua.com/arm immed encoding/index.html](https://minhhua.com/arm%20immed%20encoding/index.html)